

# PS Walkway Pad Product Data

## **Pressure-Sensitive Moulded Walkway Pad**

Simplify your next EPDM installation with RubberBond Pressure-Sensitive Walkway Pad. The RubberBond Walkway Pad is designed to protect the membrane in those areas exposed to repetitive foot traffic.

#### **Intended Uses**

- 1. Walkways must be installed at all traffic concentration points (i.e., roof hatches, access doors, rooftop ladders, etc.) regardless of traffic frequency.
- 2. Walkways must also be installed if regular maintenance (once a month or more) is necessary to service rooftop equipment.

### **Features and Benefits**

- Excellent tear and puncture resistance
- UV resistant
- Slip resistant

RubberBond Molded Walkway Pads	
Typical Properties & Characteristics*	
Colour	Black
Total Pad Thickness	9 mm +/- 10%
Performance requirements Density, pct	70
Tensile Strength, psi ASTM D 412 Unaged	500
Tear Resistance, ppi ASTM D 624 Unaged	250
Size	750mm x 750mm (30" x 30")



# Application\*

- 1. Remove excess dust and dirt from the membrane by wiping with a clean rag. To remove accumulated dirt, footprints, etc., scrub the membrane sheets with warm low-foaming soap and water and rinse with clean water.
- 2. Clean the dry membrane surface by scrubbing with clean natural fibre rags using Weathered Membrane Cleaner. Use HP-250 Primer to prime EPDM Membrane when adhering pads.
- 3. Take into account water run off direction when positioning the PS Adhesive.
- 4. Adhere Walkway Pads using HP-250 Primer. Apply primer to deck surface where tape will contact deck surface.
- 5. Allow a 25 mm wide gap between Walkway Pads. Discontinue Walkways over field seams allowing a minimum 25 mm gap.
- \* REVIEW CURRENT SPECIFICATIONS AND DETAILS FOR SPECIFIC APPLICATION REQUIREMENTS.

#### **Precautions**

The product is to be used as a walkway only and is not designed as a substitute for ballast. Walkway Pads cannot be installed within 3 m of the roof perimeter or on projects which exceed 50' (15 m) in height for Design "B" systems. Concrete pavers may be used in these areas. When installing walkways in conjunction with ballast, avoid the entrapment of small ballast below walkways.

RUBBERBOND
FLEECEBACK
EPDM ROOFING